

Fat Analysis of Meat with Smartphone Integration

Team Quadcopter: Marty Alcala, Brandon Bruen,
John Bush (JD), Philip Gordon

ECE 4012 L2A: Professor Bhatti

The FatAnalyzer

- Estimates the Fat % of Pork Chops
- Test lasts less than 10 seconds
- Android and iOS Support



Instructions

- Weigh the Pork
 - Insert Probes into opposite ends of the meat
 - Begin test on the FatAnalyzer app
 - The results are displayed on the app
-


Hardware

- Arduino Uno
 - RedBearLab Bluetooth Low Energy Shield
 - Simple set up with a 14.84 kOhm Resistor
 - Other:
 - Smartphone with the FatAnalyzer app installed
 - Scale that measures in grams
-


Software

- Arduino uses short voltage pulses to test resistance of meat
 - Current is determined with the known resistance
 - Plugs values for Resistance and Weight into the developed model
 - Send Results to the Application via Bluetooth
 - Smartphone Application
-

The System






Arduino Ohm Meter



Bluetooth

- The Arduino is connected to RedBearLab's BLE shield
 - Code is designed to actively ensure that the phone is connected to the FatAnalyzer
 - Works on iOS and Android via Cordova (Write once, run everywhere!)
-


Mobile App Interface



Biological Challenges

1. Meat begins to “charge up” slowly when a voltage is applied across it, causing the resistance reading to increase with time
 2. Used a quick pulse approach to counteract this. The results are even more interesting..
-

Biological Discoveries



Fat Computation

1. Take computed lean weight from regression
 2. Assume 35% water weight
 3. Fat weight = Total Weight - Lean Weight - Water Weight
 4. Fat percentage = Fat weight / (Non-water weight)
-

Testing

- Meat resistance was tested using the FatAnalyzer
 - That data was collected along with the weight and length of the pork
 - The Pork was then boiled down until fat and lean mass were separated and all water weight was removed
-

Specifications

Specification	Objective	Final Implementation
Target Subject	Cuts of Meat	Pork Chops
Meat Fat % Accuracy	10-20%	14%
Test Duration	<10 Seconds	<10 Seconds
Device Weight	<3 lbs	0.60 lbs
Signal Voltage	3.3 - 5 V	5 V
Number of Probes	2 - 4	2

Design Issues Encountered

- Original idea involved testing complex impedance of meat
 - Include capacitance as another parameter in the model
 - Through significant testing, it was found that complex impedance was a minimal factor
 - Issues with Microcontroller selection
 - Started and ended with Arduino
-


Design Issues Encountered

- Similarity between subjects
 - Because all subjects were prepared similarly within batches, there is very little variation between non-measured parameters within a sample group.
 - Breaks down when samples from different sources tested.
 - Non-ideal testing methods
 - A more absolute fat-testing method was cost prohibitive.
-

Next Steps

- Increased testing for parameterization of more attributes of meat.
 - Allows for a more robust model over various metrics
 - We feel this product could be much more widely applied
 - Chicken, beef, fish, etc.
 - Human testing
 - Original Plan
-

Next Steps: Human Testing



$$FFM (kg) = 0.7 * (Ht^2 / R_{body}) + .18 * BW - .18 * Age + .12 * X_{body} - 2.5 \quad [1]$$

Ht² - Height of the subject squared

R_{body} - Real resistance of subject's body




BW - Bodyweight of subject

Age - Age of subject


X_{body} - Imaginary reactance of subject's body

Demonstration

Mobile App Interface



Arduino Ohm Meter



Conclusion

- We have a product that is fairly accurate
 - This is likely due to little variation between samples
 - Weight is the most significant variable
 - As a proof of concept, this is a viable solution, but not a marketable product
 - Too many variables for such a small subject
 - Could be more viable with human subjects
-

Questions

References

- [1] N. Macias. (2007, Aug. 15). *Body fat measurement by bioelectrical impedance and air displacement plethysmography: a cross-validation study to design bioelectrical impedance equations in Mexican adults* [Online]. Available: <http://www.ncbi.nlm.nih.gov/pmc/articles/PMC2020472/#!po=3.12500>

Bibliography:

Y. Hui. (2012) *Handbook of Meat and Meat Processing, 2nd Edition*, Boca Raton

S. Nielsen. (2003) *Food Analysis Vol. 1*, New York

Y. Hui. (2001) *Meat Science and Applications*. New York
